


Parts List

HP4-927
On-Off Foot Switch

For optional use with Micromotor Kits
K.1020, K.1030, K.1070, K.1080, and K.1090



Item	Part No.	Description	Qty
1		Upper Case	1
2		Lower Case	1
3		Bottom Plate	1
4		Coil Spring	1
5		Miro Switch	1
6		Cord Holder	1
7		Rubber Foot	4
8		Foot Switch Cord	1