

Warranty

This unit has a one year warranty from the date of delivery, valid only if the unit has not been misused or tampered with. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE HEREBY LIMITED IN DURATION TO A PERIOD ENDING ONE YEAR FROM DATE OF PURCHASE, AND WE WILL NOT BE LIABLE OR RESPONSIBLE FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES.

Repair or replacement will be made at our option if the product is returned post-paid to:

The Foredom Electric Company
16 Stony Hill Road, Bethel, CT 06801

All warranty repairs must be done at the factory at the above address. We will not pay any shipping or transportation charges. This warranty only covers the original purchaser of the product. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Foredom Wax Carver Parts

Handpiece	A.WT-82
Handpiece Cap with cork cover	A.WT-84
Handpiece Cord	A.WT-86
On/Off and Temperature Control	A.WT-87
Transformer 115-220V	A.WT-85
European Plug Adapter	HPL4-508
UK Plug Adapter	HPL4-506
Australian Plug Adapter	HPL4-507

K.WC-1 & K.WC-2 includes 3 tips

Straight Taper	A.WT-2
Knife	A.WT-3
Small Spoon	A.WT-4

K.WC-3 & K.WC-4 includes all 7 Tips

Small Flat	A.WT-1
Curved Taper	A.WT-5
Large Flat	A.WT-6
Large Spoon	A.WT-7

FOREDOM[®] Wax Carver

110V. kits:
K.WC-1 and K.WC-3

220V. kits:
K.WC-2* and K.WC-4*
*with specific plug adapters for use in Europe, UK, or Australia



For Your Own Safety Read This Owner's Manual Before Operating Your Foredom Tool

FOREDOM[®]

The Foredom Electric Company, Bethel, CT 06801 www.foredom.com

For More Information on Foredom machines, handpieces or accessories, contact: The Foredom Electric Company, 16 Stony Hill Road, Bethel, CT 06801, Tel: 203-792-8622, Fax: 203-796-7861, Email: customerservice@blackstoneind.com.

Form 1263 n 3/10

Printed in U.S.A.

Important Safety Instructions


- **Warning: Tip becomes hot during operation.**
- Always turn off the unit when it is not in use.
- Never bend the handpiece cord sharply behind connector.
- Use **only** the 6 Volt DC transformer supplied with your Wax Carver.
- Keep out of reach of children.

Assembly and Operation

- Use either end of the handpiece cord to connect the output receptacle and back end of the handpiece. Connect the transformer cord to the input receptacle as shown at right.
- Plug the transformer into an electrical outlet.
- Insert a tip. The brass tips can be sharpened or reshaped with a file or bent with pliers. Follow instructions at right to remove or change a tip.
- Turn the Temperature Control Dial to desired temperature.
- The blue LED light will flash constantly when the unit is turned on and with greater frequency as the temperature increases.

Changing Tips

- Always change tips while power is on and handpiece is hot. Use a leather cloth, leather gloves, or pliers to gently turn the tip to make sure it can be loosened and safely removed.
- Never remove a tip from a handpiece that is cold. Cooled and hardened wax may act as an adhesive and damage your handpiece as you try to remove the tip.
- Each tip has a coil spring that helps it grip the handpiece heating rod. For a tighter grip, slide the coil toward the handpiece.



Approximate Tip Temperatures at Dial Settings

	Low	2	3	4	5	Max.
°F	95°	200°	340°	425°	525°	560°
°C	35°	93°	171°	218°	274°	294°

Plug Adapters for K.WC-2 and K.WC-4 kits



All 7 Brass Tips shown at left come in K.WC-3 and K.WC-4.

* 3 Tips included in K.WC-1 and K.WC-2.

Tips and Plug Adapters may also be purchased separately.