


# Parts List

## H.8D Handpiece



Item	Part No.	Description
A	HP44A	Chuck Nut
B	HP603	Standard Collet 3/32"
	HP601	Collet for 1/32" Shanks
	HP602	Collet for 1/16" Shanks
	HP604	Collet for 1/8" Shanks
	HP605	Collet for 3mm Shanks
	HP600	Set of 4 Collets (1/32", 1/16", 1/32", 1/8")
C	HP56A	Spindle
D	HP53	Chuck Guard
E	HP52	Cover Stop Screw


Item	Part No.	Description
F	HP58	Ball Bearing
G	HP54A	Housing
H	HP57	Bearing Spacer
I	HP10531	Retaining Ring
J	HP10581	Wave Spring Washer
K	HP55	Housing Coupling
L	HP76	Duplex Inner Spring
M	HP75	Duplex Axle
N	HP73	Duplex Cover Assembly
O	HP51S	Sleeve Bearing
P	HP47	Washer
Q	HP10531	Retaining Ring
R	HP46	Slotted Shaft Connector
S	HP42	Q.D. Connector
T	HP48	Catch Ball
U	HP43	Catch Spring

Not  
Shown HP10586 Wrench Assembly

**FOREDOM®**  
**The Freedom Electric Company**  
 16 Stony Hill Road, Bethel, CT USA 06801  
 203-792-8622 • Fax: 203-796-7861  
 Email: customerservice@blackstoneind.com  
 www.freedom.net

# Parts List

## H.8 Handpiece



# FOREDOM®

The Foredom Electric Company

16 Stony Hill Road, Bethel, CT USA 06801

203-792-8622 • Fax: 203-796-7861

Email: customerservice@blackstoneind.com

www.foredom.net

Item	Part No.	Description
------	----------	-------------

A	HP44A	Chuck Nut
B	HP603	Standard Collet 3/32"
	HP601	Collet for 1/32" Shanks
	HP602	Collet for 1/16" Shanks
	HP604	Collet for 1/8" Shanks
	HP605	Collet for 3mm Shanks
	HP600	Set of 4 Collets (1/32", 1/16", 1/32", 1/8")

C	HP56A	Spindle
D	HP53	Chuck Guard
E	HP52	Cover Stop Screw

Item	Part No.	Description
------	----------	-------------

F	HP58	Ball Bearing
G	HP54A	Housing
H	HP57	Bearing Spacer
I	HP10531	Retaining Ring
J	HP10581	Wave Spring Washer
K	HP55	Housing Coupling
L	HP46	Slotted Shaft Connector
M	HP42	Q.D. Connector
N	HP48	Catch Ball
O	HP43	Catch Spring

Not  
Shown HP10586 Wrench Assembly