


# Parts List

## Handpiece 44-A



Part No.	Description
HP43	Sheath Catch Spring
HP48	Sheath Catch Ball
HP61	Ball Bearing (2 required)
HP63-0	QD Sheath Connector
HP64	Chuck Nut
HP67	Chuck Wrench with Key and Chain
HP71	Bearing Retaining Nut
HP447	Collet, 1/4"
HP10007	Main Housing
HP10008	Collet Chuck
HP10043	Spindle
HP10050	Spindle for 44-A only when attached to Model A44A Flexade

**FOREDOM®**

The Foredom Electric Company  
 16 Stony Hill Rd, Bethel, CT 06801 • 203-792-8622  
 email: customer.service@blackstoneind.com • website: www.foredom.net