



WOLF TRIMMER

A-WT1727

Caution! Wear safety
glasses and dust mask!



The Wolf Trimmer slides over an H.30® handpiece and can be hand held against a bench pin, or placed in the collar of a GRS BenchMate™. Work on the right side of cylinder bur and pull wax toward you while cutting. When the bur is close to the layout line, use light pressure and long sweeping strokes for smooth cuts.



Can be used on metal with separating disk(s) to cut grooves for inlay.



For more info and free tutorials visit:

www.wolftools.com

FOREDOM®
Foredom Electric Company
www.foredom.net